Scan Code: <u>04</u>

Well # Marco #4 Location: <u>NE</u> /4; Sec <u>18</u>, T <u>19</u>N, R<u>06</u> E; <u>610'</u> F <u>S</u> L <u>840'</u> F <u>E</u> L **TECHNICAL REVIEW** Type of Injection Well: SWD/Conversion/Active Injection: Continuous Approximate # Days operating/year <u>365</u> Rate (B/M): Average __ Maximum __3000 Wellhead Pressure (psi): Average _ Maximum Fluid: TDS _ SP.GR. _ Analysis Included: [Yes/No] Source (Formation Name): <u>Skinner</u> Geologic Data (All references to depths are below land surface) Base of Historical Usable Water: Base of USDW and How Determined: 400'-well Ceasar #4, OK0163, NE/4, 18-19N-<u>06E</u> Injection Interval: Top 2756'-2800' Effective Thickness 49' Formation Name Oswego Lithology Porosity (%) 6.8 Initial Reservoir Pressure _ Date Permeability (md) 2.7 Confining Zones: Thickness between injection zone & USDW 2356' Lithology Cumulative Shale _ Thickest Shale Zone _ (Interval) Well Data: (All references to depths are below land surface) Surface Elevation GL 862' Total Depth 3482' Date Drilled or to be Drilled 2/16/82 Plugged Back Depth 2900 Date Converted Type Logs Available (this well/offset well): (By reference/included) Test Data (By reference/included) Size Sacks of Hole Cement How Depth Construction: (In.) Interval Cement Size Interval Determined Surface Csg. 8 5/8" 0-530" <u>400</u> <u>12 1/4"0-530"</u> **Calculated** Intermediate Csg. 4 1/2" 0-3480' **300** Long String Csg. 7 7/8" 3480'-1926' Calculated Liner Csg. **Tubing** Packer type & depth Tension – 2706' $ft^3/$ Lin ft / ft³ # of Total ft³ Lin. ft. $\underline{\text{of Cement}}$ X $\underline{\text{from tables}}$ = $\underline{\text{of Cement}}$ 400 1.18 300 4.3899 1554' Area of Review (AOR) (1/4 mile - Osage; 2 mile - O.I.L.) Tabulation of Wells Submitted: Yes Map Submitted: Yes Faults Located: None Present Number of Wells in AOR: Abandoned 4 Production 5 SWD EOR 0 Number of Wells in Zone of Endangering Influence Number of Wells Requiring Corrective Action: SWD _ EOR Well Well Type Problem Corrective Action Required Maximum Injection Pressure Calculation: Pm=(Frac Gradient - (.433 X SP.GR.)) X Depth $Pm = (.75 - (.433 X_{)}) X_{} = (Psi) (Used 400 psig.)$ Well **Passes** Technical Review Date <u>9/30/08</u> Reviewer <u>BH</u>

Reviewer **bh**

Date 9/30/08

Permit # **06SOKP1P9108**

Company Taylor International, Inc.